Granular Rheology in the Quasi-static, Intermediate and Rapid Flow Regimes: Towards a Comprehensive Model


Jin Sun, Sebastian Chialvo and Sankaran Sundaresan Department of Chemical Engineering Princeton University

NETL Workshop on Multiphase Flow Science Pittsburgh, PA May 4, 2010




Roadmap for dense granular flow








Key questions * addressed:



Action taken in our project:



Key questions ⁴ addressed:



Action taken in our project:

What defines the stress in quasi-static regime?

Identified internal variables defining stress states.



- 1. Fundamental aspects of stress and flow fields in dense particulate systems.
 2. Definition of material properties on relevant scales, along with efficient ways to represent properties in models and establish standards for material property measurements.
 3. Given the practical need for continuum modeling capability, identify the inherent limitations and how to proceed forward, e.g., hybrid models that connect with finer scale models (DNS, DEM, finite element, stochastic, etc.) for finer resolution.
 4. Size-scaling and process control (particle / unit-op / processing system) is critical to industrial applications.
- Action taken in our project:

- What defines the stress in quasi-static regime?
- What parameters control the transitions between granular states?

- Identified internal variables defining stress states.
- Demonstrated effects of jamming transition on flow regime transition.



- 1. Fundamental aspects of stress and flow fields in dense particulate systems.
 2. Definition of material properties on relevant scales, along with efficient ways to represent properties in models and establish standards for material property measurements.
 3. Given the practical need for continuum modeling capability, identify the inherent limitations and how to proceed forward, e.g., lybrid models that connect with finer scale models (DNS, DEM, finite element, stochastic, etc.) for finer resolution.
 4. Size-scaling and process control (particle / unit-op / processing system) is critical to industrial applications.
- *Action taken in our project:

- What defines the stress in quasi-static regime?
- What parameters control the transitions between granular states?
- Continuum rheological models from quasi-static to rapid flow regimes?(Goal II in our project)

- Identified internal variables defining stress states.
- Demonstrated effects of jamming transition on flow regime transition.
- Developed a plasticity model for the quasi-static regime and extending to intermediate regime.



- 1. Fundamental aspects of stress and flow fields in dense particulate systems.
 2. Definition of material properties on relevant scales, along with efficient ways to represent properties in models and establish standards for material property measurements.
 3. Given the practical need for continuum modeling capability, identify the inherent limitations and how to proceed forward, e.g., hybrid models that connect with finer scale models (DNS, DEM, finite element, stochastic, etc.) for finer resolution.
 4. Size-scaling and process control (particle / unit-op / processing system) is critical to industrial applications.
- *Action taken in our project:

- What defines the stress in quasi-static regime?
- What parameters control the transitions between granular states?
- Continuum rheological models from quasi-static to rapid flow regimes?(Goal II in our project)
- Represent material properties in models?

- Identified internal variables defining stress states.
- Demonstrated effects of jamming transition on flow regime transition.
- Developed a plasticity model for the quasi-static regime and extending to intermediate regime.
- Linked model parameters to particle scale properties




- 1. Fundamental aspects of stress and flow fields in dense particulate systems.
 2. Definition of material properties on relevant scales, along with efficient ways to represent properties in models and establish standards for material property measurements.
 3. Given the practical need for continuum modeling capability, identify the inherent limitations and how to proceed forward, e.g., hybrid models that connect with finer scale models (DNs, DEM, finite element, stochastic, etc.) for finer resolution.
 4. Size-scaling and process control (particle / unit-op / processing system) is critical to industrial applications.
- Action taken in our project:

- What defines the stress in quasi-static regime?
- What parameters control the transitions between granular states?
- Continuum rheological models from quasi-static to rapid flow regimes?(Goal II in our project)
- Represent material properties in models?

- Identified internal variables defining stress states.
- Demonstrated effects of jamming transition on flow regime transition.
- Developed a plasticity model for the quasi-static regime and extending to intermediate regime.
 - Linked model parameters to particle scale properties

Flow map






Scaled pressure versus scaled shear rate from steady simple shear simulations

$$\mu = 0.5$$

- Critical volume fraction distinguishes flow regimes and is related to jamming transition.
- Flow behaviors merge into the same scaling at high shear rates. 4/23

Flow map





Scaled pressure versus scaled shear rate from steady simple shear simulations

$$\mu = 0.5$$

- Critical volume fraction distinguishes flow regimes and is related to jamming transition.
- Flow behaviors merge into the same scaling at high shear rates. 4/23

Outline



- Introduction to the quasi-static constitutive model
- Model calibration for a wide range of particle friction coefficients
- Extension to predict normal stress difference
- Application to hopper flows
- Rate-dependent flow behaviors
- Future work



- Simulate particle dynamics of homogeneous assemblies under isotropic compression or simple shear using discrete element method (DEM).
- Extract stress and structural information by averaging; seek constitutive relations.



- Simulate particle dynamics of homogeneous assemblies under isotropic compression or simple shear using discrete element method (DEM).
- Extract stress and structural information by averaging; seek constitutive relations.

Stress
$$\sigma = rac{1}{V} \sum_{i}^{N} \left[m_i \mathbf{C}_i \mathbf{C}_i + \sum_{j,j
eq i} rac{1}{2} \mathbf{r}_{ij} \mathbf{F}_{ij}
ight]$$



- Simulate particle dynamics of homogeneous assemblies under isotropic compression or simple shear using discrete element method (DEM).
- Extract stress and structural information by averaging; seek constitutive relations.

Stress
$$\sigma = rac{1}{V} \sum_{i}^{N} \left[m_i \mathbf{C}_i \mathbf{C}_i + \sum_{j,j
eq i} rac{1}{2} \mathbf{r}_{ij} \mathbf{F}_{ij}
ight]$$


Coordination number: average number of contacting neighbors



- Simulate particle dynamics of homogeneous assemblies under isotropic compression or simple shear using discrete element method (DEM).
- Extract stress and structural information by averaging; seek constitutive relations.

Stress
$$\sigma = rac{1}{V} \sum_{i}^{N} \left[m_i \mathbf{C}_i \mathbf{C}_i + \sum_{j,j
eq i} rac{1}{2} \mathbf{r}_{ij} \mathbf{F}_{ij}
ight]$$

- Coordination number: average number of contacting neighbors
- Fabric tensor: average of tensor product of unit contact normals



$$A = \frac{1}{N_{c2}} \sum_{n=1}^{N} \sum_{c=1}^{c_p \ge 2} \mathbf{n_{p,c} n_{p,c}} - \frac{1}{3} I$$



$$\boldsymbol{\sigma} = p \mathbf{I} - p \eta \frac{\mathsf{S}}{|\mathsf{D}|} \qquad_{|\mathsf{D}| = \sqrt{\frac{1}{2}\mathsf{D}^{\mathrm{T}} : \mathsf{D}}}$$



$$\sigma = p \mathbf{I} - p \eta \frac{\mathsf{S}}{|\mathsf{D}|} \qquad |\mathsf{D}| = \sqrt{\frac{1}{2} \mathsf{D}^{\mathrm{T}} : \mathsf{D}}$$
 Pressure



$$\sigma = p \mathbf{I} - p \eta \frac{\mathsf{S}}{|\mathsf{D}|} \quad |\mathsf{D}| = \sqrt{\frac{1}{2}} \mathsf{D}^\mathsf{T} : \mathsf{D}$$
 Pressure $\mathsf{Macro-friction}$



$$\sigma = p \mathbf{I} - p \eta \frac{\mathsf{S} \leftarrow \mathsf{Deviatoric\ strain\ rate}}{|\mathsf{D}|} |_{|\mathsf{D}| = \sqrt{\frac{1}{2}\mathsf{D}^{\mathsf{T}} : \mathsf{D}}}$$
 Pressure \uparrow Macro-friction



$$\sigma = p | -p \eta \frac{\mathsf{S} \leftarrow \mathsf{Deviatoric strain rate}}{|\mathsf{D}|} \qquad |\mathsf{D}| = \sqrt{\frac{1}{2}\mathsf{D}^{\mathrm{T} : \mathsf{D}}}}$$
 Pressure
$$\mathsf{Macro-friction}$$
 Strain rate tensor



$$\sigma = p | -p \eta \frac{\mathsf{S} \leftarrow \mathsf{Deviatoric\ strain\ rate}}{|\mathsf{D}|} |_{|\mathsf{D}| = \sqrt{\frac{1}{2}\mathsf{D}^{\mathrm{T}} : \mathsf{D}}}} \\ \mathsf{Pressure} \qquad \mathsf{Strain\ rate\ tensor\ Macro-friction}$$

Pressure equation $pd/k = (a_1 + a_2|A|)(Z - Z_c)^2$



$$\sigma = p | -p \eta \frac{\mathsf{S} \leftarrow \mathsf{Deviatoric\ strain\ rate}}{|\mathsf{D}|} \\ \mathsf{Pressure} \\ \mathsf{Macro-friction} \\ \mathsf{Macro-friction} \\ \mathsf{Strain\ rate\ tensor}$$

Pressure equation $pd/k = (a_1 + a_2|A|)(Z - Z_c)^2$

Macroscopic friction $\eta = b_1 + b_2 \frac{A:S}{|D|}$

linked to microstructure variables

Evolution equations



Fabric tensor

$$\mathring{\mathsf{A}} = c_1 \mathsf{S} + c_2 |\mathsf{D}| \mathsf{A} + c_3 (\mathsf{A} : \mathsf{D}) \mathsf{A}$$

Jaumann derivative
$$\mathring{A} = \frac{dA}{dt} + A \cdot W - W \cdot A$$


Coordination number

$$\dot{Z} = d_1(A : D + \chi) + d_2|D|(f(\phi) - Z) + d_3 tr(D)$$
 $\dot{Z} = \frac{dZ}{dt}$


$$\chi = (c_2 + \sqrt{c_2^2 - 8c_1c_3})/2c_3)$$

The model has been verified to be able to correctly predict complex rheological behaviors during steady and unsteady flows.











ullet a_1 is a fitting parameter for pressure in isotropic compression





- ullet a_1 is a fitting parameter for pressure in isotropic compression
- It fluctuates in a small range and is modeled as a constant.






- ullet a_1 is a fitting parameter for pressure in isotropic compression
- It fluctuates in a small range and is modeled as a constant.
- Particle friction drives the jamming transition point, Z_c , to smaller values at higher friction; but scaling is universal.


Incorporating particle friction: shear pressure





Incorporating particle friction: shear pressure






 $ullet a_2$ is determined by fitting simple shear pressure with a constant $a_{I.}$

Incorporating particle friction: shear pressure






- a_2 is determined by fitting simple shear pressure with a constant a_1 .
- \circ a_2 is modeled as a linear function of particle friction.







Incorporating particle friction: shear stress ratio




$$\eta = b_1 + b_2 \frac{\mathsf{A} : \mathsf{S}}{|\mathsf{D}|} \stackrel{0.5}{\overset{0.25}{\overset{0.25}{\overset{0.15}{$$

 $oldsymbol{artheta}$ is a function of particle friction agreeing with previous studies.*

Incorporating particle friction: shear stress ratio





- $oldsymbol{artheta}$ is a function of particle friction agreeing with previous studies. *
- b_1 and b_2 vary with particle friction as: $b_1 = -0.16e^{-6\mu} + 0.16e^{-6\mu}$ $b_2 = 1.6e^{-6\mu} 2.9$

^{*}W. R. Ketterhagen, J. S. Curtis, C. R. Wassgren, and B. C. Hancock. Powder Technology, 195(1):1-10, 2009.

Incorporating particle friction: microstructure



Fabric tensor

$$\mathring{\mathsf{A}} = c_1 \mathsf{S} + c_2 |\mathsf{D}| \mathsf{A} + c_3 (\mathsf{A} : \mathsf{D}) \mathsf{A}$$

Coordination number


$$\dot{Z} = d_1(A : D + \chi) + d_2|D|(f(\phi) - Z) + d_3tr(D)$$

- Material constants c_1 - c_3 and d_1 - d_3 have little dependence on friction coefficient.
- ullet The main effect on Z_c and ϕ_c is implemented in the function

$$f(\phi) = Z_c + \beta_1 (\phi - \phi_c)^{\frac{1}{2}}$$


Z and ϕ correlation





Z and ϕ correlation






ullet eta_1 is modeled as a constant.

Z and ϕ correlation






- Θ β_1 is modeled as a constant.
- ullet ϕ_c is determined from this correlation, thus related to jamming transition.


Z and ϕ correlation






- ullet ϕ_c is determined from this correlation, thus related to jamming transition.
- It decreases with particle friction coefficient.










Steady-state simple shear

Normal stress components are different from each other with deviation of 5-10% from the mean pressure.






- Normal stress components are different from each other with deviation of 5-10% from the mean pressure.
- Two extra terms to capture normal stress differences

$$\boldsymbol{\sigma} = p\mathbf{I} - p\eta \frac{\mathsf{S}}{|\mathsf{D}|}$$






- Normal stress components are different from each other with deviation of 5-10% from the mean pressure.
- Two extra terms to capture normal stress differences

$$\boldsymbol{\sigma} = p\mathbf{I} - p\eta \frac{\mathsf{S}}{|\mathsf{D}|} + a_3 p(\mathsf{A}\hat{\mathsf{D}} + \hat{\mathsf{D}}\mathsf{A} - \frac{2}{3}\mathsf{A}:\hat{\mathsf{D}}\mathsf{I})$$






- Normal stress components are different from each other with deviation of 5-10% from the mean pressure.
- Two extra terms to capture normal stress differences

$$\boldsymbol{\sigma} = p\mathbf{I} - p\eta \frac{\mathsf{S}}{|\mathsf{D}|} + a_3 p(\mathsf{A}\hat{\mathsf{D}} + \hat{\mathsf{D}}\mathsf{A} - \frac{2}{3}\mathsf{A} : \hat{\mathsf{D}}\mathsf{I}) + a_4 p(\mathsf{A} - \frac{(\mathsf{A} : \mathsf{D})\mathsf{S}}{\mathsf{D} : \mathsf{D}})$$






$$\sigma_{xx} = \sigma_{zz} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$

$$\sigma_{yy} = p(1 - \frac{4}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$





$$\sigma_{xx} = \sigma_{zz} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$


$$\sigma_{yy} = p(1 - \frac{4}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$

$$\sigma_{xx} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}) + a_4A_{xx})$$

$$\sigma_{zz} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}) + a_4A_{zz})$$

$$\sigma_{yy} = p(1 - \frac{4}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$





$$\sigma_{xx} = \sigma_{zz} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$

$$\sigma_{yy} = p(1 - \frac{4}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$

$$\sigma_{xx} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}) + a_4A_{xx})$$

$$\sigma_{zz} = p(1 + \frac{2}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}) + a_4A_{zz})$$


$$\sigma_{yy} = p(1 - \frac{4}{3}a_3A_{xz}\operatorname{sgn}(\dot{\gamma}))$$

a₃ and a₄ are also made functions of particle friction

Application to conical hopper flow



- Classical theories* do not take account of microstructure change.
- What is the effect of microstructure evolution?
- Compare to the hour-glass theory*.
- Solve the model for flows in a conical hopper assuming:
 - incompressible flow
 - smooth side walls
 - stress-free surface
 - radial gravity



^{*} R. M. Nedderman. Statics and Kinematics of Granular Materials.

One-dimensional equations




Scaled microstructure and stress equations in a spherical coordinate system

Scaled fabric
$$\frac{dA_{rr}}{d\hat{r}} = -\frac{1}{\hat{r}}(2c_1 + \sqrt{3}c_2A_{rr} + 3c_3A_{rr}^2)$$


$$\begin{array}{ll} \text{Scaled stress} & \frac{d\hat{\sigma}}{d\hat{r}} = \frac{2\phi\hat{V}^2}{\hat{r}^5} + \frac{2(\kappa-1)\hat{\sigma}}{\hat{r}} - \phi \\ \\ \hat{r} = \frac{r}{R_{\mathrm{out}}} & \hat{\sigma} = \frac{\sigma}{\rho_s g R_{\mathrm{out}}} & \text{Flow rate } \hat{V} = \frac{V}{\sqrt{R_{\mathrm{out}}^5 g}} \\ \end{array}$$

 $\ ^{\wp}$ $\ ^{\wp}$ is a function of η in our model, but is constant in the hour-glass theory.











Stress profile is similar to that of hour-glass theory.





- Stress profile is similar to that of hour-glass theory.
- Normal stress difference affects the prediction.






- Stress profile is similar to that of hour-glass theory.
- Normal stress difference affects the prediction.
- Macro-friction varies in the flow direction and values agree with DEM simulations*.

^{*}A.V. Potapov and C. S. Campbell. Physics of Fluids, 8(11):2884–2894, 11 1996.

Intermediate pressure behaviors






Collapse pressure data of assemblies with volume fractions $\phi > \phi_c$ using $(p-p_{\rm QS})d/k = \alpha |\tilde{\rm D}|^n$

 p_{QS} is the pressure at the quasi-static state.

Intermediate pressure behaviors






- Same relation works for a range of particle friction.
- G. I. Tardos, S. McNamara, and I. Talu. Powder Technology, 131(1):23-39, 2003.

Intermediate stress ratio






Macroscopic friction coefficients collapse onto one curve when plotted against inertia number*

$$I = \dot{\gamma}d/\sqrt{p/\rho_s\phi}$$

^{*}P. Jop, Y. Forterre, and O. Pouliquen. *Nature*, 44 I (7094):727–730, 2006.

Intermediate stress ratio





- The collapse works for all the friction coefficient studied.
- ullet The η scaling with I and correlation with friction are being examined. $_{22/23}$

Work in progress



- Complete the model according to the flow behaviors shown for intermediate regime
- Extend the model to include rapid to intermediate flow transition
- Apply the model to compressible hopper flows

Acknowledgment

O. NE